
The core switch is configured with a DHCP server



Overview

Solved: Configure dhcp on core switch Below are the dhcp configs for the core switch. "Service DHCP" is enabled. "IP Routing" is enabled on the core switch.

Key Takeaways

You can configure a Cisco core switch as a DHCP server by creating DHCP pools, assigning default gateways, and ensuring VLANs and trunk links are properly set up. Step 1: Enable DHCP ServiceEnsure the DHCP service is enabled on the core switch. On most Cisco Layer 3 switches, DHCP is enabled by default, but you can verify with: CodeCopyshow running-config | include service dhcp If disabled, enable it with: CodeCopyservice dhcp Step 2: Create DHCP PoolsEnter global configuration mode and create DHCP pools for each VLAN: CodeCopySwitch# configure terminalSwitch(config)# ip dhcp excluded-address 192.

168. 1. 1 192.

168. 1. 10Switch(config)# ip dhcp pool VLAN10Switch(dhcp-config)# network 192.

168. 1. 0 255.

255. 255. 0Switch(dhcp-config)# default-router 192.

168. 1. 1Switch(dhcp-config)# dns-server 8.

8. 8. 8Switch(dhcp-config)# exit Repeat for other VLANs as needed.

© 2026 BAGYOU FIBRE NETWORKS · All rights reserved

Excluded addresses are reserved for static devices like routers or servers. Step 3: Configure VLAN Interfaces (SVIs)Assign IP addresses to VLAN interfaces on the core switch: CodeCopySwitch(config)# interface vlan 10Switch(config-if)# ip address 192. 168.

1. 1 255. 255.

255. 0Switch(config-if)# no shutdownSwitch(config-if)# exit Ensure each VLAN used by access switches has an SVI on the core switch. Step 4: Configure Trunk Links to Access SwitchesEnsure the links connecting the core switch to access switches are configured as trunks: CodeCopySwitch(config)# interface gigabitEthernet 1/0/1Switch(config-if)# switchport mode trunkSwitch(config-if)# switchport trunk encapsulation dot1qSwitch(config-if)# exit This allows multiple VLANs to pass between core and access switches.

Step 5: Verify DHCP ConfigurationCheck the DHCP bindings and active leases: CodeCopySwitch# show ip dhcp bindingSwitch# show running-config | section dhcp You can also enable debugging to troubleshoot: CodeCopySwitch# debug ip dhcp server eventsSwitch# debug ip dhcp server packet This helps confirm that clients are receiving IP addresses from the core switch. Step 6: Save ConfigurationFinally, save the configuration to ensure it persists after a reboot: CodeCopySwitch# copy running-config startup-config By following these steps, your core switch will act as a DHCP server, providing IP addresses to clients connected through access switches while maintaining proper VLAN segmentation and routing.

Article Content

Solved: Configure dhcp on core switch

Below are the dhcp configs for the core switch. "Service DHCP" is enabled. "IP Routing" is enabled on the core switch and the two access switches. These are dummy IP addresses, and the

Configuring DHCP

Because the DHCP clients and their associated DHCP server do not reside on the same IP network or subnet, a DHCP relay agent (the Catalyst switch) is configured with a helper address to enable

How to Configure DHCP Server on Cisco Switches

This tutorial explains how to configure, test, and verify a DHCP server on a Cisco switch through a packet tracer example.

Typical DHCP Configuration

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

The DHCP server function based on the global address pool should be configured on a core device, or an exclusive DHCP server be used to assign network parameters such as IP addresses.

Configure DHCP Server for multiple VLANs on the Switch

This tutorial explains how to configure and run the DHCP service on a Cisco switch to support multiple VLANs.

Sx300 Series Switches Typical Configuration Examples (V200)

As shown in Figure 6-6, an enterprise deploys the DHCP server on the core switch. The DHCP server and terminals in the enterprise belong to different network segments.

How to configure DHCP Server on Cisco IOS

Cisco IOS routers and layer 3 switches can be configured as DHCP servers. It''s quite easy to do this and in this short lesson, I want to explain to you how to do this and how to verify your configuration.

DHCP Server Configuration in Cisco Switch

Dynamic Host Configuration Protocol, or DHCP, is a network protocol used (via DHCP server) to dynamically or automatically assign IP address and other info (e.g.Gateway,DNS) to each hosts in

Configuring DHCP on Routers and Switches

Configuring a Cisco Router as a DHCP Server. Cisco IOS has a built-in DHCP server. Configuring it requires defining a pool (the range of addresses to assign), excluding any static addresses, and

Two-Tier Core

Prepare switches for deployment in Aruba Central for building a Two-Tier Data Center. The L2 Two-Tier Data Center uses an MC-LAG core for performance and redundancy connected to

How many DHCP Servers should a network have? : r/sysadmin

I have two DHCP servers set up at work in fail over mode. Most places I have worked have had a single DHCP server configured to service multiple subnets. You can have as many DHCP servers as you

Comptia A+ 220-1201 Core 1 Flashcards | Quizlet

- Requires a DHCP server - Server, appliance, integrated into a SOHO router, etc. • Dynamic / pooled - IP addresses are assigned in real-time from a pool - Each system is given a lease and must renew at

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Service | Kubernetes

Expose an application running in your cluster behind a single outward-facing endpoint, even when the workload is split across multiple backends.

Configure Network Settings on Windows with

In Windows, you can manage the settings for your network adapters not only from the GUI but also from the PowerShell command prompt. In this

How to Fix a 500 Internal Server Error

A "500 Internal Server Error" is a message you might see when browsing the web. It means something went wrong on the website''s server, but the server can''t pinpoint the exact issue.

Configure a Server Core installation of Windows Server and Azure

Here are some things to keep in mind about SConfig: Starting with Windows Server 2022 (deployed with the Server Core installation option) and Azure Local automatically run SConfig after

What''s New with vSphere in VMware Cloud Foundation 9.1?

Zero touch provisioning does not require an external TFTP server. Configure the UEFI boot URL to point to the vCenter and boot the host over the network. A DHCP server is required if

Network Configuration Basics: Everything You Should

Configurations here directly shape your defenses. VLAN and Network Segmentation VLANs group devices logically, while segmentation isolates

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved

Contact Us

Continue your research online:

Website: https://bagyou.es
Technical inquiry: https://bagyou.es/project-enquiry.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 BAGYOU FIBRE NETWORKS - All rights reserved